

User Defined Values & Photometric Parameters

1. Go to the Light's **Type Properties**, click the Edit/ New Button and change the **Value** for **Model** by replacing all missing Ordering Information which is designated with a series of "X's".

2. Click the **IES File Link** button the the far right of the **Value** Column and begin downloading the Zipped file from Kenall.com. *Open the Zipped file and copy the files the your clipboard.*

3. Click the **Photometric Web File** button which opens the **Select File** dialog box for the default IES files location.

4. **Paste** the files you copied in Step 2. into the default IES folder

5. Select then **Open** the correct IES file.

Note: The Parameter named Photometric Web File comes with the following Values:

Predefined Values (ES5-48-2-32-CP.IES in the example to the right)

User Required input Values (Requires searching in the zipped files found via IES File Link in See Step 2.)

Not available (Contact Kenall as required)

